

Corrugator Roll Wear Measurement

Contents

Foreword / iii

1.	Roll wear measurement methods	1			
	Direct subjective methods			Relatively new roll with some pitting (white areas in valleys)	
	Direct objective methods			Worn roll with chrome gone (white area in valley)	
	Indirect methods				
2.	Suitability of various methods	5			
	Pressure profiles (NCR strips)			Suggested procedure	
	Staining (copper sulfate)			Typical flute gauge	
	Micrometer/depth dial gauge				
	Roll impressions				
	Noncontact measurement				
	IPC/McMahon abrasiveness				
3.	Methods to obtain pressure profiles of corrugating rolls	7			
4.	Typical pressure profiles	9			
	Typical new roll pressure patterns			Actual plaster impression from roll	
	Overall roll wear			Thin sections as they appear in optical comparators	
	Worn out rolls				
	Pitted rolls				
	Chipped rolls				
5.	Copper sulfate test	15			
	Suggested procedure				
				6. Typical staining patterns	17
				7. Flute depth gauge use	19
				8. Depth dial gauge use	21
				Suggested procedure	
				9. Full plaster casting and optical comparators	23
				10. Direct contact coating wear measurement	25
				<i>Bibliography / 27</i>	