Cellulose nanofiber nanocomposite for flexible and wireless electronics

Teahoon Park
Korea Institute of Materials Science



CONTENTS



- 1 Introduction of KIMS
- Nanofibrillation of cellulose
- os Flexible electronic device application
- 04 Conclusion





KIMS (Korea Institute of Materials Science)





Purpose of Establishment

To support national research projects and policies and lead the development of the knowledge industry through supporting, fostering, and systematically managing Government-funded Research Institutes (hereinafter, "GRIs") in the field of science and technology


Government-funded Research Institutes (GRIs) under the NST

We would like to introduce our 25 research instites

Korea Institute of Science and Technology	GREEN TECHNOLOGY CENTER	KOREA BASIC SCIENCE INSTITUTE	Korea Astronomy and Space Science Institute	Xonea Institute of Science and Technology Information
KIOM	KRIBB Manual Provides of Street	Extract Patrick	Datonia and Meteromotarium Search bertain	NSR Countries
KICT KINA WITH/IF J DA INGKIENS WE ERLENS TICHNILOR	Korea Railroad Research Institute	KRISS	KOPEA FOOD RESEARCH POSTITUTE	WiKim World Institute of Kimchi
KIGAM Kons historie of Geochesce and filteral filteraccis	KIMM KOREA INSTITUTE OF MACHINERY & MATERIALS	KONGA ÉMOGRACI BERMONI	ρ <mark>₂로</mark> 한국에나지기술연구완 κοθεί καπίνε οΓ μεκογαίαθεσι	KERI KOREA ELECTROTECINIOLOGY RESEARCH INSTITUTE
KRICT Save Freezed technique	Korea Institute of Toxicology	KAERI Research Institute	KIMS Korea Institute of Materials Science	KFE KOREA INSTITUTE OF FUSION ENERGY

KIMS (Korea Institute of Materials Science)








As a government funded research institute, our objective at KIMS is to comprehensively facilitate R&D, test and evaluation and provide technical support related to materials technology in order to promote innovative technology and industrial development.



Cellulose



Cellulose nanomaterials at KIMS




IVIFC	TOCHF	CIVC				
Morpholgy						
Uneven width of 10-2000 nm forming bundles	Uniform width 3~5 nm, several um in length	Uneven width of 5-10 nm, < 300 nm in length				
Energy consumption in nano-conversion						
<700~1400 MJ kg ⁻¹	<7 MJ kg ⁻¹	<7 MJ kg ⁻¹				


- Fabrication of MFC, TOCNF by using pulp, cotton, and lyocell
- CNC fabrication by using cotton

KIMS CNF



CNF fabrication and morphology





Current Opinion in Green and Sustainable Chemistry 2018, 12:15–21

TEM image

Zeta potential result

- TEMPO catalyst is introduced to produce TOCNF through electrostatic repulsive force through substitution of COO- functional groups on the surface of CNF
- Manufacture CNF by the high-pressure homogenizer equipment
- Similar CNF morphology to other references
- Width: 5 nm, length: several um
- Zeta potential : -56 ± 4.6 mV, Stably dispersed state


KIMS CNF



CNF dispersion concentration control and aerogel fabrication



8 % CNF dispersion




1% dispersion and aerogel for composite

- High concentration dispersion for nanocomposite applications
- Aerogel or sponge for resin infusion process

Tracing the fibrillation of cellulose



Scheme of nanofibrillation by ultrasonication and homogenizer





Ref: Cellulose, https://doi.org/10.1007/s10570-020-03410-4, 2020, T.Park.

Nanofibrillation of cellulose



Nanofibrillation process





Ref: Cellulose, https://doi.org/10.1007/s10570-020-03410-4, 2020, T.Park.

Morphology and rheological property of CNF ***

Fibrillation tracing and modulus comparison




Fig. TEM images of TOCNF nanofibrillated using (a, b) high-intensity ultrasonication with surface charge density of (a) 0.879 and (b) 1.24 mmol/g and (c) high-pressure homogenizer with different surface charge densities.




Fig. Oscillatory strain sweep measurement for 0.5 % TOCNF suspensions disintegrated by (a-c) HIUS and (d) high-pressure homogenizer with different surface charge densities

Degree of nanofibrillation prediction method


TAH 18-3 Alia


Development of modeling that traces back the fibrillation process from the perspective of rheology

Table 1 Average width of TOCNF with different nanofibrillation methods and surface charge densities

Surface charge density (mmol/g cellulose)	Nanofibrillation method	Fibrillation time (s)	Avg. width (nm)	SD (nm)
0.659	HIUS	120	_	
		180	_	
		360	4.24	0.98
		600	3.93	0.98
	High-pressure homogenizer	_	3.86	0.93
0.879	HIUS	120	5.46	1.37
		180	4.34	1.51
		360	4.13	1.02
		600	3.82	1.07
	High-pressure homogenizer	_	3.84	1.10
1,24	HIUS	30	8.23	4.33
		60	5.48	1.39
		90	2.88	0.71
		120	3.04	0.80
	High-pressure homogenizer	_	3.20	0.67


→ Yield stress of 0.5 % TOCNF suspensions versus (a) sonication treatment time and (b) average width of the nanofibers as a function of surface charge densities. Solid lines indicate the yield stresses of TOCNF suspensions individualized using high-pressure homogenizer with different surface charge densities. (red: 0.659, blue: 0.879, and black: 1.24 mmol/g)











1 2 3 4 5 6 7 8 9 10

https://www.uvindex.app/vancouver





Air pollution (ozone depletion)



Ultraviolet (UV) light exposure on earth increase



Causes harmful diseases (sunburn, skin cancer, cataracts)




Demands for evaluating the intensity of UV in day life




***UV lamp applications**






















Research goal (suggested)





ZnO nanomaterials for sensing



*ZnO nanostructure for UV-sensing material








- 1. An environmentally friendly semiconductor
- 2. Band gap of 3.35 eV
- 3. Various synthetic methods, diverse processing technologies
- 4. Operating at high temperatures and in harsh environments.

Nanostructure → Large surface area → High sensitivity

ZnO nanomaterials for sensing



*** UV sensing mechanism of ZnO devices**




- Oxygen molecules are adsorbed onto ZnO surfaces by capturing free electrons which creates a low-conductivity depletion layer
- Upon UV illumination, hole discharge the negatively charged adsorbed oxygen ions to photodesorb oxygen from the surfaces or effectively get trapped at the ZnO surfaces, resulting in an increase in the free carrier concentration


Objectives

To synthesize ZnO nanorods by solution-processing method with controlling the length of them to understand the affects of the length of ZnO nanorods on ZnO nanorods based UV sensors.






ZnO NRs synthesis by controlling the concentration of zinc precursors in the seeding and growth processes, respectively.




FE-SEM images of ZnO nanomaterials synthesized from different Zinc precursor concentrations of the growth reactions. (a) 0.5M, (b) 1M, (c) 2M, and (d) 3M concentration (Scale bar = 1 μ m). Enlarged images (50,000x magnification) of the ZnO products (e) 0.5M, (f) 1M, (g) 2M, and (h) 3M respectively (Scale bar = 200 nm).






TEM images of ZnO nanomaterials with different aspect ratio synthesized from controlled precursor concentration such as (a) 0.5M, (b) 1M, (c) 2M, and (d) 3M. The crystal structure images and diffraction pattern of the product (e) 0.5M, (f) 1M, (g) 2M, and (h) 3M respectively.





TEM and XRD pattern of ZnO nanomaterials with different aspect ratio





Optoelectric properties of ZnO NRs under repeated UV irradiation on and off

3.10

1.25

 5.55×10^{-1}

 1.09×10^4

18.6 / 27.3

Nano Conference 2023

3 M







Figure. (a) Five times repeated photocurrent measurement under different UV intensity irradiation (162–840 μ W/cm²) (b) The photocurrent vs. UV intensity plot and linear fit for the calibration curve. (R² = 0.99)


ZnO NR

(b)





- (a) A schematic diagram of the circuitry for wireless ZnO NR UV sensor platform connected with a smartphone.
- (b) A photographic image of the Bluetooth-connected ZnO NRs UV sensor module (left) and a smartphone display showing the dark current value in real time (right).
- (c) Photographic images of the wireless ZnO NRs UV sensor operation under repeated UV light on/off.



Nano Conference 2023 27

KIMS UV SENSOR




* How to make a flexible sensor? A fiber type?





Further research



PDMS + ZnO nanorods Composite (1:1 weight ratio)











Transferred Composite (ZnO nanorods embedded PDMS)









	Dark current	On current	On/off ratio
ZnO NRs/PDMS	-	-	1.84
Transferred ZnO NRs/PDMS	3.74 x 10 ⁻⁸	3.26 x 10 ⁻⁶	88.9

The optoelectronic properties of ZnO NRs/PDMS composite sensor



***** ZnO nanorods and CNF composite film for a flexible sensor





A schematic image of the fabrication of flexible CNF+ZnO NRs composite sheet UV sensor operating appropriately under atmospheric conditions based on the porous matrix materials.



Optical property of ZnO nanorods and CNF composite films


(a) Cellulose Nanofiber & ZnO Nanorod Composite

Cellulose Nanofiber & ZnO Nanorod Composite

(b) Cellulose Nanofiber & ZnO Nanorod Composite

Cellulose Nanofiber & nO Nanorod Composite







Photographic images of free-standing (a) CNF sheet, (b) CNF-ZnO SNR composite sheet, and (c) CNF-ZnO LNR composite sheet. (d) UV-Vis (Transmittance) spectra of CNF sheet and CNF+ZnO NR composite sheets.



Crystal structure and thermal analysis of the composite sensor




XRD pattern of CNF film and CNF-ZnO NR composite films with different lengths of ZnO NRs.



TGA spectra of CNF, ZnO, and composites




Optoelectronic properties



(a) Optoelectronic properties of ZnO NRs under repeated UV irradiation on and off (Intensity: from 128 to 645 μ W/cm²). (b) I-V curve of ZnO NR UV sensors.



Optoelectronic properties





- (a) Optoelectric properties of ZnO NRs under different UV irradiation and bias potential.
- (b) The photocurrent vs. UV intensity plot and linear fit for the calibration curve. ($R^2 = 0.99$)



Verification of flexibility and implementation of the wireless platform







Photographic images of the bending test and resistance change plot







- Design and manufacture of wireless circuits
- Development of a prototype in the form of a smartwatch
- Development of a smartphonelinked wireless sensing platform



Conclusion



- Cellulose nanofibers were fabricated by delicate nano fibrillization.
- The rheology properties were suggested to estimate the degree of nano fibrillization.
- Aspect ratio controlled ZnO nanorods were successfully synthesized via two-step processes.
- As the length of ZnO nanorods was longer, UV responsivity was 58.5 times higher.
- Flexible sensors with high sensitivity based on inorganic and organic 1-dimensional nanomaterials.
- Cellulose nanofibers can make a porous nano matrix for inorganic sensing materials.
- Composites sensor was successfully prepared for wearable devices.

Acknowledgement



KIMS MEMBERS



RESEARCH FIELDS

Conductive polymer synthesis and their applications Flexible energy harvester Organic photo-electric materials

CNT & Graphene composites
Carbon fiber composites
Fiber-based energy storage, sensor
Sustainable polymer composite
Cellulose-based nano-composite (Insulation, SAP)

